
MASTECH® M58922A







MASTECH[®]

Introduction

The Voltage Tester provides a simple and fast method of testing AC and DC voltage up to 400 volts. The different indicating signals of the Voltage Tester are not to be used for measuring purposes, it only means a voltage range. not the exact value. For example, when 120V indicator lights up, the measured voltage is in the range of 120V, it meant that the measured voltage value may be 120V, may be less than 120V, may also be greater than 120V.

Marnings

- Read, understand and follow the Safety Rules and Operating Instructions in this manual before using this instrument.
- The Voltage Tester is designed to be used by the skilled persons and in accordance with safe methods of work.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Unauthorized persons are not to be allowed to disassemble the tester.
- Keep fingers away from the metal probe tips when taking measurements.
- · Comply with all safety codes. Use approved personal protective equipment when working near live electrical circuits.
- Use caution on live circuits. Voltages above 30V AC RMS, 42V AC peak, or 60V DC pose a shock hazard.
- Do not use if the instrument or test leads appear damaged.
- Measure known voltage with the tester to verify that the tester is working properly. If the tester is working

MASTECH

abnormally, stop using it immediately. A protective device may be damaged. If there is any doubt, please have the tester inspected by a qualified technician.

- Do not use the tester in wet or damp environments or during electrical storms.
- Do not use the tester near explosive vapors, dust or gasses.
- Do not use the tester if it operates incorrectly. Protection may be compromised.
- Do not apply voltage that exceeds the tester's maximum rated input limits.

Input Limits

Function	Maximum Input
Voltage DC, Voltage AC	400V


Maintenance

- 1.KEEP THE TESTER DRY. If it gets wet, wipe it off.
- 2.USE AND STORE THE TESTER IN NORMAL TEMPERATURES. Temperature extremes can shorten the life of the electronic parts and distort or melt plastic parts.
- 3 HANDLE THE TESTER GENTLY AND CAREFULLY. Dropping it can damage the electronic parts or the case.
- 4.KEEP THE TESTER CLEAN. Wipe the case occasionally with a damp cloth. DO NOT use chemicals, cleaning solvents, or detergents.

MASTECH[®]

Voltage Tester Description

- 1 External test probe (-)
- 2.Instrument test probe (+)
- 3.LEDs for voltage display
- 4. Protection ring





↑ Keep your fingers behind the protection ring when measuring.

MASTECH[®]

International Safety Symbols

\triangle	Caution, risk of danger
Ŕ	Caution, risk of electric shock
	Equipment protected throughout by double insulation or reinforced insulation.
\triangle	Suitable for live working
\sim	Both direct and alternating current
c Usus Usus Intertek	Conforms to UL STD. 61010-1, 61010-2-030 and 61010-031; Certified to CSA STD C22.2 NO. 61010-1, 61010-2-030 and 61010-031
C€	Conforms to relevant European Union directives
CATIII	MEASUREMENT CATEGORY III is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.
OVC III	OVERVOLTAGE CATEGORY III is for equipment intended to form part of a building wiringinstallation.
IP54	Representing the level of protection from specified external conditions. 5: Dust-protected; 4: Protected against splashing water

MASTECH[®]


AC/DC Voltage Measurements

⚠ Warnings

Observe all safety precautions when working on live voltages.

- 1. Touch the test probes across the circuit being measured.
- 2. The tester will turn on automatically if the voltage exceeds 12 volts.
- 3. The LEDs will indicate the voltage.
- 4.For AC voltage, the "+" and "-" LEDs will illuminate.
- 6.For DC voltage, the "+" LED will illuminate if the instrument test probe is touching the positive side of the circuit. The "-" LED will illuminate if the instrument test probe is touching the negative side of the circuit.

MASTECH[®]



MASTECH[®]

Specifications

Specifications		
Voltage LED steps	±12,24,50,120,230,400V	
Accuracy	-30% to 10% of indication	
Response time	<0.1s	
AC frequency range	50/60Hz	
Operation time	30s maximum	
Recovery time	10 minutes after maximum operation time has been reached	
Operating Temperature	5°F to 113°F(-15°C to 45°C)	
Storage temperature	5°F to 122°F(-15°C to 50°C)	
Relative Humidity	80% maximum	
Altitude	7000ft(2000m)	
Safety	CAT III 400V,OVC III 400V ≂	
Weight	98.5g	
Dimension	223x40x32 mm	



04 05 06 00-05-4054